




set up
guide

simplehuman®

quick start

1 insert batteries



- use a screwdriver to remove battery cover
- insert 4 AA batteries as shown

Note: Only use alkaline batteries.

2 fill the reservoir



- lift off the lid on top of the chamber to fill


Note: Do not use soap with exfoliants, and be careful not to overfill.

3 prime the pump




- place your hand under the sensor
- hold down + button until soap comes out

tip: priming problem?



If the soap isn't flowing, use a pin or paperclip to lightly poke the valve opening.

Be careful not to push too far or puncture the surrounding rubber area.



adjust the volume

To change the amount dispensed, press + or - buttons at the front of the pump.

on/off

Press and hold - button to turn the pump off, press + button to turn on.

continuous dispensing

Press and hold + button to dispense soap continuously.

low battery alert

LED will turn red during operation to indicate low battery.



use & care

- Your sensor pump dispenses soap, hand sanitizer, or lotion. Please keep it simple: avoid soaps with exfoliants or beads.
- To clean, wipe pump with a damp cloth—do not submerge in water or use in the shower.

Questions?

Find answers easily online:

www.simplehuman.com/service