




set up  
guide

simplehuman®

# quick start

## 1 insert batteries



- use a screwdriver to remove battery cover
- insert 4 AA batteries as shown

**Note:** Only use alkaline batteries.

## 2 fill the reservoir



- lift off the lid on top of the chamber to fill


**Note:** Do not use soap with exfoliants, and be careful not to overfill.

## 3 prime the pump




- place your hand under the sensor
- hold down **+** button until soap comes out

**tip:** priming problem?



If the soap isn't flowing, use a pin or paperclip to lightly poke the valve opening.

**Be careful not to push too far or puncture the surrounding rubber area.**



## adjust the volume

To change the amount dispensed, press **+** or **-** buttons at the front of the pump.

## on/off

Press and hold **-** button to turn the pump off, press **+** button to turn on.

## continuous dispensing

Press and hold **+** button to dispense soap continuously.

## low battery alert

LED will turn red during operation to indicate low battery.



## use & care

- Your sensor pump dispenses soap, hand sanitizer, or lotion. Please keep it simple: avoid soaps with exfoliants or beads.
- To clean, wipe pump with a damp cloth—do not submerge in water or use in the shower.

## Questions?

Find answers easily online:

[www.simplehuman.com/service](http://www.simplehuman.com/service)